FEEL THE GAME

Immersion

for PS3™

LAVA GLOW WIRELESS

DUAL MOTOR RUMBLE TECHNOLOGY

dreamGEAR

www.dreamgear.net

PACKAGE CONTENTS:
1. Lava Glow Controller
2. Lava Glow Receiver

SET-UP:

1. Open the battery compartment located on the bottom side of the Lava Glow controller. Insert 3 "AAA" batteries. Replace battery lid.

2. The Lava Glow controller features a 3 position power switch located on the bottom side of the controller.

OFF = The controller is powered OFF

ON = This setting allows you to have full use of your Lava Glow controller without the internal LEDs illuminating. This setting conserves battery life.

LED = The controller and LEDs are powered ON

3. With your PlayStation 3 game console powered "ON", plug the USB Receiver into your PlayStation 3's USB input #1 (or other, if using multiple controllers). The LED will flash slowly. Press the "CONNECT" button on the Receiver, the LED will flash rapidly.

4. Press the "MENU" button on the Lava Glow controller, the four channel indicators (located above the "MENU" button) will flash rapidly. Press the "MENU" button again and the channel will automatically be set. The solid LED indicates the chosen channel.

5. To connect multiple controllers, connect each controller separately. First connect player 1's controller and then connect the remaining controllers.

6. During gameplay, you can access the PlayStation 3 menu by holding the "MENU" button for 3 seconds.

TURBO FUNCTION:
1. The Lava Glow controller features a "TURBO" mode. To activate "TURBO", press any button and the "TURBO" button at the same time to set "TURBO" to that button. To cancel the "TURBO" function, repeat step #1.

NOTE: If the controller stops functioning properly, replace batteries.
NOTE: The Lava Glow controller is NOT compatible with SIXAXIS game play.

FCC NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try the interference by one of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications made on the system not expressly approved by the manufacturer could void the user's authority to operate equipment. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or e-mail support@dreamgear.net

dreamGEAR®
P.O. BOX 478
Torrance, CA 90508
www.dreamgear.net

TouchSense® Technology Licensed from Immersion Corporation. Protected by one or more of the following patents:

U.S. Patents: 4823634, 4896554, 5184319, 5185561, 5220260, 5235868, 5389865, 5414337, 5459382, B1 5459382, 5482056, 5513100, 5559412, 5576727, 5589854, 5592401, 5623582, 5629594, 5631861, 5676157, 5691898, 5701140, 5721566, 5724264, 5731804, 5734373, 5739811, 5767839, 5769640, 5790108, 5805140, 5821920, 5825308, 5828197, 5831408, 5844392, 5872438, 5880714, 5889670, 5889672, 5907487, 5929607, 5930741, 5929846, 5956484, 5959613, 5999168, 6015473, 6020875, 6020876, 6020967, 6024576, 6028593, 6037927, 6042555, 6046727, 6050718, 6050962, 6057828, 6059506, 6061004, 6067077, 6078308, 6078876, D427635, 6088017, 6088019, 6100874, 6101530, 6104158, 6104379, 6104382, 6106301, 6110130, 6125337, 6125385, 6128006, 6131097, 6134506, 6147674, 6148280, 6154198, 6154201, 6161126, 6162190, 6166723, 6169540, 6184868, 6191774, 6195592, 6201533, 6211861, 6215470, 6219032, 6219033, 6232891, 6243078, 6246390, 6252579, 6252583, 6256011, 6259382, 6271828, 6271833, 6275213 B1, 6278439, 6281651, 6285351, 6288705, 6292170, 5754023, *RE37374, 6292174, 6300936, 6300937, 6300938, 6304091, 6310605, 6317116, 6323837, 6342880, 6343349, 6348911, 6353850, 6353427, 6366272, 6366273, 6374255, 6380925, 6396232, 6400352, 6411276, 6413229, 6424333, 6424356, 6429846, 6428490, 6433771, 6437771, 6448977, 6469692, 6470302, 6486872, 6497672, 6563487, 6564168, 6580417, 6636161, 6636197, 6639581, 6654000, 6661403, 6680729, 6683437, 6686901, 6686911, 6693622, 6693626, 6697043, 6697044, 6697048, 6697748, 6697086, 6703550, 6704001, 6704002, 6704683, 6705871, 6707443, 6715045, 6750877, 6762745, 6781569
Europe: 0843808, 0803114, 0870296, 0804786, 0974889; Australia: 649655, 670311, 671705, 734986, 735467, 762226, 770385; Canada: 2271129, 2139336, 2278726, 2122047, 2167304, 2233206, 2210725, 2075178, 2272379, 2261893, 2287349, 2223289; France: 852770 (EP), 609363 (EP), 00/01312; Germany: 29923332.4, 29922298.5, P69231634.5 (EP), 69607189 (EP), 29923623.4, 20014425.1, 20021536.1, 20102767.4, 20080209.7, 29923933, 20022244.9, 20180024.1, 20080263.1, 20080275.5, 20200955.6; Italy: 1315182, 852770 (EP), 609363 (EP); Japan: 3084433, 3085481, 3069791, 2000-008994, 2000-001158, 3290436; Korea: 257172, 258353, 252706; Sweden: 519661; Switzerland: 852770 (EP), 609363 (EP); Taiwan: UM-108174; United Kingdom: 23449730, 2346455B, 2347990, 2349731, 2346952, 2384613, 2350698B, 2387241B, GB2387218, GB2353116, 609363 (EP), 852770 (EP), 2343499